

 **eclipse**
profil

 **eclipse**
BCP

 **amplitude**



Surgical Technique Out-In






Summary

Concept and range	5
Surgical technique overview	7
Step 1 - Harvesting and graft preparation	8
Step 2 - Tibial placement	9
Step 3 - Tibial drilling	10
Step 4 - Femoral placement	11
Step 5 - Femoral drilling	12
Step 6 - Relay loop passing	13
Step 7 - Graft positioning	14
Step 8 - Femoral fixation	15
Step 9 - Tibial fixation	16
Instrumentation	18
Annexe A Femoral Outside-in guide	20
Annexe B Modular tibial guide	21
Annexe C Modular tibial guide: Assembly	22
Annexe D Tibial guide: Modification of the angulation	23
Annexe E Out-In femoral guide : Assembly	24




Concept and range





Surgical technique overview


1 Harvesting and graft preparation




2 Tibial placement




3 Femoral placement



4 Graft fixation




1 Harvesting and graft preparation




Use the open stripper to harvest the semitendinosus and gracilis tendons.
Prepare and suture the graft as usual. You can preserve the tendons insertion.

Calibrate (diameter and length) the graft
using graft sizer.



2 Tibial placement



Assemble the tibial guide and choose the angulation.

Insert the tibial guide through the medial portal. Then, place the tibial guide tip on the ACL footprint.


The laser mark indicates the exit point of the wire pin guide.

Insert the tibial guide sleeve, flat surface facing upwards until you hear a single «clic» after the contact with the cortex.

Drill the 2.4mm wire pin guide through the modular tibial guide sleeve.

Check the wire pin guide position, remove the tibial guide from the joint.

3 Tibial drilling



Place a drill that matches the graft diameter over the wire pin guide.

Drill the tibial tunnel.

Remove the drill.

4 Femoral placement



Assemble the femoral guide.

Hook the posterior notch in the «over the top position».


Make a skin incision in front of the modular guide sleeve.

Insert the modular guide sleeve through the skin incision until cortex contact.

Drill the wire pin guide through the modular guide sleeve. The pin guide exit 7mm anterior to the hook.

Remove the guide from the joint. Then check the wire pin guide position.

5 Femoral drilling




Place a drill that matches the graft diameter over the wire pin guide.

Drill the femoral tunnel from extra-articular to intra-articular.

Remove the drill.

6 Relay loop passing




Pass the suture passing loop through the wire inserter.

Pass the wire inserter through the femoral tunnel.

Pass the passing suture from the joint through the tibial tunnel.

The loop come out the tibial tunnel.

7 Graft positioning



Suture wire of the graft is passed through the passing suture loop.

Pull the passing suture at the femoral level until the graft suture wire exit to the femoral tunnel.

Pull the graft suture wire until the graft take in place in the knee.

8 Femoral fixation



Tapping:

Pull the suture wire of the graft at the femoral level.

Place the screw guide wire into the femoral tunnel.

Pass the starter tap or the shank starter through the femoral tunnel over the screw guide wire.

Thread the tunnel.

Screwing:

Put the Shank Screwdriver ECLIPSE BCP/Profil or the Shank Screwdriver ECLIPSE BCP/Profil Ø7-12mm onto ratcheting handle.

Keep the graft suture wire tension.

Put the interference screw (ECLIPSE BCP or PROFIL) onto the universal screwdriver Biomatlante Ø 7-8-9-10-11-12mm or the shank screwdriver.

9 Tibial fixation



Tapping:

Pull the suture wire of the graft at the tibial level.

Place the screw guide wire into the femoral tunnel.

Pass the starter tap or the shank starter through the tibial tunnel over the screw guide wire.


Thread the tunnel.

Screwing:

Put the interference screw ECLIPSE BCP or PROFIL onto the shank screwdriver ECLIPSE Ø 7-12mm or the shank screwdriver ECLIPSE BCP / PROFIL.


Keep the graft suture wire tension.

Insert the screw into the tibial tunnel over the screw guide, keep the graft suture wire tension.



Instrumentation


ACL outside-in instrumentation: High tray



Rep	Description	Reference	Qty
1	Femoral slide AM 7mm	2-0405800	1
2	Landanger chas 300mm	J80200	1
3	Graft sizer	2-0401800	1
4	Open stripper Ø 5mm	2-0405505	1
5	Modular tibial guide sleeve	2-0404900	1
6	Modular guide body/handle	2-0404800	1
7	Modular tibial aimer	2-0405000	1
8	Wire pin guide Ø2.4mm Lg 300mm	2-0405600	1

Instrumentation


ACL outside-in instrumentation: Low tray



Rep	Description	Reference	Qty
1	Canulated drill Ø 6mm	2-0402906	1
	Canulated drill Ø 7mm	2-0402907	1
	Canulated drill Ø 8mm	2-0402908	1
	Canulated drill Ø 9mm	2-0402909	1
	Canulated drill Ø 10mm	2-0402910	1
	Canulated drill Ø 11mm	2-0402911	1
2	Ratcheting handle	2-0406400	1
3	Shank screwdriver ECLIPSE Ø7-12 mm Trinkle	2-0409300	1
OR			
4	Shank screwdriver ECLIPSE BCP / PROFIL	2-0406200	1
5	Shank starter ECLIPSE BCP / PROFIL	2-0406300	1
6	Wire Nitinol Ø 1.1mm length 300 mm	15INBR001F10	1
7	Screw guidewire Ø 1.1mm length 240 mm	2-0405700	1
Option:			
8	Universal screwdriver Biomatlante Diameter screw 7-12mm	16INTO001	1
9	Tap for interference screws L20-25-30 mm	11INTA001	1


Appendix A

Femoral Outside-in guide




Appendix B

Modular tibial guide




- Angulation 45° to 70°.
- The pin will exit in the blend of the guide.



Annexe C

Modular tibial guide: Assembly




- ▶ Insert the modular aimer into the modular guide handle to select angulation (1).
- ▶ Lock the guide (modular tibial aimer + modular guide handle) by pulling the blue handle towards the guide handle (2).

Working: Move the lock down press the blue handle and move the lock up to block the modular tibial guide sleeve.

- ▶ Insert the modular tibial guide sleeve into the modular guide handle, flat surface facing upware (3).
- ▶ The modular tibial guide sleeve cannot be inserted if the modular guide handle and aimer are not locked correctly. if tis occurs, remove the aimer from the guide handle. Reassemble the handle and aimer, then reinsert the guide sleeve.

Annexe D


Tibial guide: modification of the angulation



- Turn the guide sleeve a quarter turn (1).
- Remove the modular tibial guide sleeve (2).
- Unlock the tibial guide by pulling the lock downwards. This action releases the lock and the tibial guide sleeve (3).
- Change the angulation of the guide.
- Lock the guide then place the modular tibial aimer flat surface facing upware.

Annexe E

Out-In femoral guide: Assembly



- ◆ Insert the femoral aimer AM 7mm into the modular guide handle at 90°.
- ◆ Lock the guide (modular slide AM 7mm + modular guide handle) by pulling the blue handle towards the guide handle.
- ◆ Slide the guide sleeve through the guide, flat part facing upwards.



Products availability may vary depending on countries. Please check availability with your local representative.

Service Clients – France :

Porte du Grand Lyon,
01700 Neyron – France
Tél. : **+33 (0)4 37 85 19 19**
Fax : +33 (0)4 37 85 19 18
E-mail : amplitude@amplitude-ortho.com

Customer Service – Export :

11, cours Jacques Offenbach,
ZA Mozart 2,
26000 Valence – France
Tél. : **+33 (0)4 75 41 87 41**
Fax : +33 (0)4 75 41 87 42

www.amplitude-ortho.com